


### Operating Instructions for Automatic Control Package for 311 Series Tilt-To-Load Drum Tumblers with Serial Number 246333 - \_\_\_\_\_



MORSE MFG. CO., INC.•727 West Manlius Street•P.O. Box 518•East SynPhone: 315-437-8475•Fax: 315-437-1029•Email: service@MorseDrum.com•West


East Syracuse, NY 13057-0518 • Website: MorseDrum.com



### Operating Instructions for Automatic Control Package for 311 Series Tilt-To-Load Drum Tumblers with Serial Number 246333 - \_\_\_\_\_


Step2 Functions that are not set on the DIP switch are set using front panel keys.

Switch from RUN mode to Function Setting mode.






Operating Instructions for Automatic Control Package for 311 Series Tilt-To-Load Drum Tumblers with Serial Number 246333 - \_\_\_\_\_



3



Operating Instructions for Automatic Control Package for 311 Series Tilt-To-Load Drum Tumblers with Serial Number 246333 - \_\_\_\_\_





Operating Instructions for Automatic Control Package for 311 Series Tilt-To-Load Drum Tumblers with Serial Number 246333 - \_\_\_\_\_

Present Value	Set Value	Meaning	Recovery
23	No display	Memory error (RAM)	Turn the power OFF and ON again. If normal operation is still not restored, it may be necessary to repair or replace the H5CX. If the display is restored to normal, then a probable cause can be exter nal noise affecting the control system. Check for external noise.
23	5Uñ	Memory error (EEP)	All settings are initialized to the factory setting when pressing Reset key.
Ε Ι	No display	CPU error	Reset Key or power cycled.
Phone	: 1-847-84		Fax: 1-847-843-7787
Phone	: 1-416-28 EAN H.Q. :	OMRON EU	DA) Fax: 1-416-286-6648 ROPE B.V. (NETHERLANDS) Fax: 31-23-56-81-388
			TD. (AUSTRALIA)
	: 02-9878-		Fax: 02-9878-6981
DMRON	ASIA-PAC	IFIC PTE.LT	D. (SINGAPORE)
		Sec. 22 (2) (2)	Fax: 65-6-835-2711

5